

PDR-OPS-001 EXTREME COLD TESTING PROTOCOL FOR ROBOTIC JOINTS

PDR-OPS-001 EXTREME COLD TESTING PR

Document Classification: **CONFIDENTIAL**

Version: **3.2**

Effective Date: **January 15, 2024**

Document Owner: **Chief Robotics Officer**

1. PURPOSE AND SCOPE

1 This Protocol establishes the mandatory testing procedures for all r

2 This Protocol applies to all BlueCore(TM)-enabled joint systems, including:

- a) Primary articulation joints
- b) Secondary mobility assemblies
- c) End-effector connection points
- d) Load-bearing pivot mechanisms

2. DEFINITIONS

1 "Test Unit" refers to any robotic joint assembly or subassembly subject to testing.

2 "Testing Cycle" means one complete sequence of temperature exposure and testing.

3 "Critical Failure" means any malfunction that results in:

- a) Loss of positional accuracy exceeding 0.5mm
- b) Torque deviation greater than 5% from baseline

- c) Response latency exceeding 50ms
- d) Structural deformation or material compromise

3. TESTING REQUIREMENTS

1 Environmental Parameters

- 1.1 Temperature Range: -40 C to +25 C
- 1.2 Humidity: 20% to 85% RH
- 1.3 Testing Duration: Minimum 72 hours per unit
- 1.4 Atmospheric Pressure: 101.3 kPa ± 1 kPa

2 Testing Sequence

- 2.1 Baseline Performance Recording (at +20 C)
- 2.2 Gradual Temperature Reduction (-5 C per hour)

2.3 Cold Soak Period (8 hours minimum)

2.4 Operational Testing at Target Temperature

2.5 Recovery Phase

2.6 Post-Test Performance Validation

4. TESTING PROCEDURES

1 Pre-Test Requirements

1.1 Calibration verification of all testing equipment

1.2 Visual inspection of Test Unit

1.3 Documentation of Test Unit serial number and configuration

1.4 Installation of temperature monitoring sensors

2 Testing Operations

- 2.1 Execute minimum 1,000 articulation cycles at each temperature point
- 2.2 Record torque measurements at 100-cycle intervals
- 2.3 Monitor power consumption throughout testing period
- 2.4 Document any anomalies or deviations from expected performance

5. DATA COLLECTION AND REPORTING

1 Required Measurements

- 1.1 Joint position accuracy (0.1mm)
- 1.2 Torque output (0.1Nm)
- 1.3 Power consumption (0.1W)
- 1.4 Response time (1ms)
- 1.5 Operating temperature (0.5 C)

2 Documentation Requirements

2.1 Complete test logs with 5-minute sampling intervals

2.2 Video recording of critical test phases

2.3 Raw sensor data in Company-approved format

2.4 Test engineer observations and notes

6. ACCEPTANCE CRITERIA

1 Performance Standards

1.1 Maintain 95% of baseline torque capability

1.2 Position accuracy within 0.3mm

1.3 No visible damage or deformation

1.4 Return to baseline performance after recovery

2 Failure Conditions

2.1 Any Critical Failure as defined in Section 2.3

2.2 Three consecutive measurements outside specified ranges

2.3 Visible damage or degradation of Test Unit

2.4 Failure to return to baseline performance

7. SAFETY AND COMPLIANCE

1 All testing must comply with Company Safety Protocol SP-LAB-001.

2 Testing personnel must maintain current cold environment safety certification.

3 Emergency shutdown procedures must be readily accessible.

8. PROPRIETARY INFORMATION

1 This Protocol contains confidential and proprietary information of Po

2 Disclosure or distribution without written authorization is strictly proh

9. REVISION HISTORY

Version 3.2 - January 15, 2024

-

Updated temperature range specifications

-

Added new data collection requirements

-

Revised acceptance criteria

Version 3.1 - July 1, 2023

- - 8 -

Modified testing cycle parameters

-

Updated safety compliance references

10. APPROVAL AND AUTHORIZATION

APPROVED BY:

Dr. James Barrett

Chief Robotics Officer

Date: January 15, 2024

Sarah Nordstrom

Chief Operating Officer

Date: January 15, 2024

