

# **PDR-OPS-012: COLD START PROCEDURES FOR AUTOMATED ASSEMBLY LINE**

## **PDR-OPS-012: COLD START PROCEDURES**

**Document Classification: CONFIDENTIAL**

**Version: 3.2**

**Effective Date: January 15, 2024**

**Document Owner: Operations Department**

**Approved By: Sarah Nordstrom, COO**

### **1. PURPOSE AND SCOPE**

1. This document establishes mandatory procedures for initiating cold

2. These procedures apply to all PDR Series 7000 and 8000 autonomous

## **2. DEFINITIONS**

1. "Cold Start" refers to the initialization of AMR assembly line operation
2. "Critical Components" include BlueCore(TM) power cells, navigation
3. "Operating Temperature Range" refers to the specified temperature

## **3. SAFETY REQUIREMENTS**

1. Personnel Requirements

-

Minimum two (2) certified PDR technicians must be present

- - 2 -

Valid Cold Environment Safety certification required

-

Appropriate cold-weather PPE must be worn at all times

## 2. Environmental Monitoring

-

Continuous temperature monitoring required

-

Humidity levels must be recorded

-

Air pressure differentials must be maintained within 5% of specified v

## 4. PRE-START INSPECTION PROCEDURES

## 1. Physical Inspection

- a) Verify integrity of all thermal insulation
- b) Check for ice formation on critical components
- c) Inspect seal integrity on all enclosures
- d) Confirm proper alignment of guide rails and tracks

## 2. System Diagnostics

- a) Run BlueCore(TM) diagnostic sequence
- b) Verify battery charge levels exceed 85%
- c) Confirm navigation sensor calibration
- d) Test emergency stop functionality

# 5. STARTUP SEQUENCE

### 1. Primary Power Initialization

- a) Engage main power distribution unit
- b) Monitor voltage stabilization for 300 seconds
- c) Verify proper phase alignment
- d) Confirm UPS backup systems are operational

### 2. Thermal Management Activation

- a) Initialize heating elements sequentially
- b) Monitor temperature gradients
- c) Verify thermal expansion compensation
- d) Confirm coolant circulation (where applicable)

### 3. Control System Boot Sequence

- a) Initialize master control unit

- b) Load operating parameters
- c) Establish network connectivity
- d) Verify redundant control systems

## **6. VALIDATION REQUIREMENTS**

### **1. System Checks**

-

All diagnostic indicators must show green status

-

Network latency must be <50ms

-

Power draw within 10% of specifications

-

Temperature differentials within 2 C of setpoint

## 2. Documentation Requirements

-

Complete startup checklist (Form PDR-OPS-012A)

-

Log all parameter readings

-

Record any anomalies or deviations

-

Obtain supervisor sign-off

## 7. EMERGENCY PROCEDURES

1. In case of system failure during cold start:

a) Execute emergency shutdown sequence

b) Notify facility supervisor immediately

c) Document all observations

d) Initiate incident report (Form PDR-OPS-012B)

## **8. COMPLIANCE AND DOCUMENTATION**

1. All cold start procedures must comply with:

-

OSHA Standard 1910.147

-

PDR Safety Protocol PS-2024-01

-

ISO 13849-1:2015 requirements

-

Client-specific safety requirements



2. Required Documentation

- Completed startup checklist
- Environmental condition log
- System performance data
- Technician certification records

9. REVISION HISTORY

Version	Date	Description	Approved By
---	---	---	---
2	2024-01-15	Updated thermal parameters	S. Nordstrom

1 | 2023-09-30 | Added BlueCore(TM) diagnostics | J. Barrett

0 | 2023-06-15 | Major revision | E. Frost

## 10. AUTHORIZATION

This document is authorized by:

...

—

Sarah Nordstrom

Chief Operating Officer

Polar Dynamics Robotics, Inc.

Date: January 15, 2024

...

## **11. DISCLAIMER**

This document contains proprietary and confidential information belonging to Polar Dynamics Robotics, Inc. Unauthorized reproduction or distribution is strictly prohibited. PDR reserves the right to modify these procedures without notice. Failure to follow these procedures may result in equipment damage, personal injury, and/or voiding of warranty coverage.

