ROBOT PERFORMANCE QUALIFICATION PROTOCOL

ROBOT PERFORMANCE QUALIFICATION P

Document ID: PDR-QP-2024-001

Effective Date: January 15, 2024

Version: 1.2

Classification: CONFIDENTIAL

1. PURPOSE AND SCOPE

1 This Robot Performance Qualification Protocol ("Protocol") establish

2 This Protocol applies to all BlueCore(TM)-enabled AMR models, inc
2. DEFINITIONS
1 "Qualification Testing" means the systematic evaluation of AMR per
2 "Test Environment" refers to the Company's Cold Chamber Testing
3 "Performance Criteria" means the measurable parameters defined i
4 "BlueCore(TM) System" refers to the Company's proprietary cold-er
3. TESTING PREREQUISITES
1 Equipment Requirements:
-

Calibrated temperature monitoring systems	
-	
Certified load simulation equipment	
-	
Navigation obstacle course components	
-	
Data logging and analysis software	
-	
Safety monitoring systems	
2 Documentation Requirements:	
-	
Manufacturing batch records	
-	
Component traceability documentation	

- 3 Calibration certificates
 Risk assessment documentation
 Standard operating procedures

4. PERFORMANCE QUALIFICATION PROCEDURES

1 Environmental Conditioning

Stage 1: Room temperature baseline (4 hours at 20 C)

Stage 2: Gradual temperature reduction (-2 C per hour)

_

Stage 34 Cold soak at target temperature (minimum 12 hours)
2 Navigation Testing
a) Obstacle Course Navigation:
-
Complete standardized course with 95% accuracy
-
Maximum deviation from planned path: 50mm
- Minimum of 50 successful iterations
b) Sensor Performance:
-
LIDAR range accuracy within 20mm
-

Camerasystem maintaining 30fps at -30 C

Successful object recognition rate >99%

3 Load Handling

Static load test at rated capacity

Dynamic load handling at 75% rated capacity

Emergency stop testing under load

Acceleration/deceleration within specified parameters

4 Power Systems

6 -
Battery performance at minimum temperature
-
Charging system functionality
-
Power consumption monitoring
-
Thermal management system verification

5. ACCEPTANCE CRITERIA

1 Critical Parameters:

-

Navigation accuracy 95%

_

Battery nuntime 8 hours at -30 C

Emergency stop response time 100ms

System boot time 120 seconds

2 Performance Metrics:

Zero critical system failures

Maximum 0.1% navigation errors

Successful completion of 100 continuous operational cycles

All sensor systems maintaining specified accuracy

6. DATA COLLECTION AND ANALYSIS

1 Required Data Points:
-
Temperature logs (ambient and critical components)
-
Navigation accuracy measurements
-
Power consumption metrics
-
System response times
-
Error logs and fault conditions
2 Analysis Requirements:

9 -
Statistical analysis of performance data
_
Trend analysis for critical parameters
-
Deviation investigations and documentation
_
Performance comparison against specifications

7. QUALIFICATION REPORT

1 The Qualification Report shall include:

•

Executive summary

_

Raw data logs
-
Statistical analysis results
-
Deviation reports and investigations
-
Conclusion and recommendations
-
Supporting documentation
8. APPROVAL AND CERTIFICATION
1 Qualification approval requires sign-off from:
-
Quality Assurance Manager

- 11 -

Chief Robotics Officer

_

Validation Engineer

_

Safety Officer

9. LEGAL DISCLAIMERS

- 1 This Protocol is confidential and proprietary to Polar Dynamics Robe
- 2 Any modification to this Protocol must be approved through the Cor
- 3 This Protocol shall be reviewed and updated annually or as required

AUTHORIZATION APPROVED BY: Dr. James Barrett Chief Robotics Officer Date: Victoria Wells Quality Assurance Manager

Date:

[Name]₁₃ Validation Engineer

Date:

[Name]
Safety Officer

Date:

